

Release Note

| | | | | |
|------------------------|--|-----|---------|---|
| Mac Touch Panel Driver | PN-L851H/ PN-L751H/ PN-L651H/ PN-L805H/ PN-L705H/ PN-L803CA/ PN-L703WA/ PN-L603WA/PN-L803C / PN-L703W / PN-L703A / PN-L703B / PN-L603W / PN-L603A / PN-L603B/ PN-C703B / PN-C603D / PN-L401C /PN-L501C PN-C805B / PN-C705B / PN-C605B/ PN-85TH1/ PN-75TH1/ PN-65TH1/ PN-80TH5/ PN-70TH5/ PN-80TC3A/ PN-70TW3A/PN-60TW3A/PN-80TC3 / PN-70TW3 / PN-70TA3 / PN-70TB3 / PN-60TW3 / PN-60TA3 / PN-60TB3 / PN-70SC3 / PN-40TC1 / PN-50TC1 PN-80SC5 / PN-70SC5 / PN-60SC5 / PN-65SC1 | Mac | 2.5.2.1 | - Supported following models PN-L851H/ PN-L751H/ PN-L65TH1/ PN-85TH1/ PN75TH1/ PN-65TH1 |
|------------------------|--|-----|---------|---|